MANAGE R S C

Paratransit Vehicle Inspection Guide

Date:	Operator:	Unit #:
Pre-Trip I	nspection	
Inter	or:	
Whee	chair Securement System	
	Check to assure all necessary straps are present, including a spare set	
	Check straps for damage, wear, dirt, debris, and contamination	
	Check ratchet straps for proper operation (self-adjusting or manual)	
	Check hooks and buckles for cracks, unusual bends, and rust	
	Check vehicle securement tracks for debris, damage, or rust	
Equip	nent	
	Proper securement of loose/spare equipment (oxygen, spare wheelchair)	
	Safety equipment (first aid kit, traffic vest, cones, flares, fire extinguisher, etc.)	
	Passenger comfort items (umbrella, poncho, blankets, etc.)	

DISCLAIMER: This is a sample guideline furnished to you by Glatfelter Commercial Ambulance. Your organization should review this guideline and make the necessary modifications to meet your organization's needs. The intent of this guideline is to assist you in reducing exposure to the risk of injury, harm or damage to personnel, property and the general public. For additional information on this topic, contact our Risk Control Representative at 800.233.1957.



Exterior:		
	Check for proper tire inflation or tire damage	
	Check for body damage	
	Check exterior lighting for proper function. Check lenses for cracks/clarity (All lighting to include high/low beam, turn signals, four way flashers, reverse, and brake lights)	
	Check window glass for cracks/chips or obscured visibility	
Lift System:		
Follow	the manufacturer's recommended procedures	
	Check for damage, misaligned, or worn parts and hydraulik leaks	
	Check door securement devices	
	Check controller buttons and cables	
	Operate lift (one complete cycle minimum) checking for smooth operation and speed	
	Check lift lighting	
	Traffic cones present to mark outside corners of lift deployment	
	Check the roll stop plate for proper platform angle to ground	
	Check for manual hand pump handle	
	Check hand pump valve to assure it is properly closed	

DISCLAIMER: This is a sample guideline furnished to you by Glatfelter Commercial Ambulance. Your organization should review this guideline and make the necessary modifications to meet your organization's needs. The intent of this guideline is to assist you in reducing exposure to the risk of injury, harm or damage to personnel, property and the general public. For additional information on this topic, contact our Risk Control Representative at 800.233.1957.



_		
Manual Ramp:		
	Check ramp for damage and proper stowage	
	Traffic cones present to mark outside corners of ramp deployment	
	Chech for ease of operation	
	Check proper angle to ground	
	Check ramp surface (free from dirt and debris)	
	Return ramp to stowed position (note excess noise or grinding)	
D.		
Pleas	se note any deficiencies:	

DISCLAIMER: This is a sample guideline furnished to you by Glatfelter Commercial Ambulance. Your organization should review this guideline and make the necessary modifications to meet your organization's needs. The intent of this guideline is to assist you in reducing exposure to the risk of injury, harm or damage to personnel, property and the general public. For additional information on this topic, contact our Risk Control Representative at 800.233.1957.

